



# Proteus PCB Design Starter Kit

## Entry Level Professional PCB Design Tools

### Summary

The PCB Design Starter Kit is the entry level product in our professional PCB design suite. It contains everything you need to create high quality, professional boards of modest size and complexity. The layout size is limited to 500 physical pins in the netlist and some of the more advanced features are excluded.

The main software modules included with the product are:


- Professional Schematic Capture Module.
- ProSPICE Professional Simulation Engine.
- Professional PCB Layout Module (500 Pins)
- Shape Based Autorouting Engine.

---

### Included Features

The following features are all included with the PCB Design Starter Kit Product.

- True Hierarchical Schematic Design.
- Fully Customisable Bill of Materials Reporting Module.
- Support for product Assembly Variants.
- Interactive Design Explorer with Cross Probing.
- Project Notes module (Documentation Centre).
- Formal Design Re-use with Project Clips/Design Snippets.
- BSDL and PADS ASCII Library Part Import Tools.
- Hardware Accelerated Display with Layer Transparency.
- Comprehensive Design Rule Configuration.
- Design Rule Aware Interactive Routing.
- Adaptive Shape Based Autorouter.
- Automatic Power Plane Generation (limited to one per layer).
- Gerber Export.

 *You cannot make PCB boards with more than 500 pins with the PCB Design Starter Kit.*


## Excluded Features

The following features comprise the Advanced Feature Set and are not included with the PCB Starter Kit.

- x Automatic Length Matching / Net tuning of routes.
- x Multiple Power Planes per Layer (e.g. an Analog Ground and Digital Ground).
- x User drawn Power Planes of specific dimensions. \*
- x Adaptive Shape Based Autorouter in scriptable or interactive mode. \*\*
- x Dynamic Teardrops.
- x 3D Board Visualisation.
- x ODB++, IDF, STEP and IGES Output Formats.
- x Autoplacement of components.

*\* Power planes must cover the entire layer (board edge to board edge) and cutouts or keepouts are not supported.*

*\*\* The shape based autorouter can only be run in fully automated mode (i.e. it will attempt to route the whole board).*

 *The features listed above are only available in the PCB Design Level 2, Level 2+, Level 3 and Platinum Edition.*

With continual development on the Proteus Design Suite we endeavour to keep all content updated with the latest product details. On rare occasions this may not happen immediately, and website content will then be incomplete or inaccurate. We will attempt to correct any such errors as soon as possible, E&OE.